

Quick Guide

Content:

- 1) Five eSATA Enclosure
- 2) 1 eSATA 1 meter cable
- 3) Screw and Key
- 4) 1 power cable

Sbox-P Quick Reference

- 1) Remove the SBOX from its packaging.
- 2) Turn off the Key Lock and take out the inner tray from each of the mobile rack.
- 3) Open the upper cover of the tray.
- 4) Fix the hard drive with the screws to the HDD orientation, close upper cover.
- 5) Use the key to lock the tray as to turn on the mobile rack. To turn off the mobile rack, simple turn the key to the unlock position.
- 6) Use the 1 meter eSATA cable to connect the SBOX to the eSATA PCI controller.
- 7) Install the Java SATARaid utility that can be found in the driver CD under GUI folder of your specific SATA host controller. (refer to the manual on how to setup you raid or jbod)
- 8) You should be able to see the drive(s) in disk management once you setup your raid or jbod. (In window 2K and XP, right click on my computer, manage and then click on disk management.)